



Item	OKU part No.	Qty	Designation
1	00031539	1	Coupling (for manual use)
	00031547	1	Coupling (for machine use)
2	00003463	1	O-Ring
3	00350297	1	Compression spring
4	00004082	1	Hexagon nut M8
5	00470944	1	Hand grip EP-Car
6	00350667	1	Piston disk
7	00003507	1	Lip seal
8	00000613	1	Eyebolt
9	00000627	1	Hexagon nut M6
10	00350670	1	Compression spring, inner
11	00350669	1	Compression spring, outer
12	00250052	1	Push rod 8 (EP-8) *
	00250051	1	Push rod 9 (EP-9) *
	00250050	1	Push rod 10 (EP-10) *
13	00350671	1	Feeding pipe 8 (EP-8)
	00350711	1	Feeding pipe 9 (EP-9)
	00350726	1	Feeding pipe 10 (EP-10)
14	00350666	1	Retaining ring
15	00000796	1	Circlip
16	00004709	1	Set screw
17	00470185	1	Intermediate piece EP-PKW
18	00350922	1	Union nut
19	00003466	1	O-Ring *
20	00470649	1	Separating finger (single-flange studs)
	00470651	1	Separating finger (multi-flange studs)
21	00417280	1	Spring lock *
22	00000582	1	Spring dowel pin
23	00485167	3	Spreader finger *
24	00353730	3	Centering finger *
25	00350668	1	Lock washer
26	00470214	1	Gun head EP-8
	00470215	1	Gun head EP-9
	00470218	1	Gun head EP-10
27	00004100	2	Hexagon socket head cap screw

Item	OKU part No.	Qty	Designation
28	00470092	1	Trigger (manual use)
	00470093	1	Trigger (machine use)
29	00000536	1	Dowel pin
30	00003464	1	O-ring *
31	00003404	1	O-ring
32	00350728	1	Bushing

00885027	1	corrosion preventive-oil, aerosol can 100 ml (single) *
00885028	1	grease, tube 20 g (single) *
20015510	1	1 aerosol can corrosion preventive-oil (100 ml) and 1 tube grease (20 g) as maintenance-set

To the gun there is available a spare parts-set including the most important wear parts. It contains all in the spare parts list with \* marked parts inclusive grease and corrosion preventive-oil-spray.

OKU-Id.-No. spare parts-set **EP-8:**                   **20015505**  
 OKU-Id.-No. spare parts-set **EP-9:**                   **20015506**  
 OKU-Id.-No. spare parts-set **EP-10:**               **20015507**